

Verricelli Verticali

Vertical Windlasses

MANUALE DI INSTALLAZIONE E D'USO - INSTALLATION AND USER'S MANUAL
MANUEL D'INSTALLATION ED D'UTILISATION - MANUAL DE INSTALACIÓN Y USO
INSTALLATION UND BEDIENUNG

CONSERVARE QUESTO MANUALE A BORDO
STORE THIS MANUAL ON BOARD
CONSERVER CE MANUEL À BORD
DIESSEN HANDBUCH AN BORD AUFBEWAHREN
GUARDAR ESTE MANUAL A BORDO

SX3.5



UK



Low Profile

With drum

Lofrans[®]
WINDLASSES
THE ORIGINAL WINDLASS



Via Philips, 5 - 20052 Monza (MB) (Italy)
www.lofrans.com - e-mail: contact@lofrans.com



Dear Customer,

Thank you for choosing a Lofrans product. Lofrans is a leader company in the production and worldwide distribution of nautical systems manufactured according to the most modern technologies, in compliance with international regulation requirements and the most important certifying bodies. All our products are manufactured with excellent materials suited for operations in marine environments and are subject to continuous checks to improve the qualitative levels and make them without any manufacturing defects. Together with such requirements, Lofrans anchor windlasses are a synthesis of reliability and efficiency, by guaranteeing the maximum performances during each phase of mooring, even in the most difficult. With a Lofrans product, years of reliable operations are guaranteed.

Lofrans ©copyright, 2023. All rights reserved.

Lofrans declines any liability for possible inaccuracies due to print errors in this manual and reserves the right to introduce any changes deemed appropriate. For this reason, Lofrans does not guarantee the accuracy of the manual after the date of issue and declines all liability for possible errors and omissions.

TABLE OF CONTENTS

1 INTRODUCTION	3	5.2 Weighing the anchor	9
1.1 Purpose of the manual	3	5.3 Use of the warping drum	9
1.2 Assistance	3	5.4 Notes for use	10
1.3 Receipt and storage	3		
2 SAFETY INFORMATION	3		
3 INSTALLATION	4	6 MAINTENANCE	10
3.1 Contents of the package	4	6.1 Maintenance programme	10
3.2 Equipment necessary for installation	4	6.2 Gipsy maintenance/replacement	11
3.3 Recommended accessories	4		
3.4 General requirements for installation	4	7 TROUBLESHOOTING	11
3.5 Prevention from electrolysis	5		
3.6 Deck thickness	5	8 TECHNICAL DATA	14
3.7 Deck installation	5		
3.8 Under deck installation	5	9 SPARE PARTS	15
3.9 Chain insertion	6		
4 ELECTRICAL SYSTEM	6	10 OVERALL DIMENSIONS	18
4.1 Electrical cable section	6		
4.2 Solenoid valves (Control Box)	6	11 DRILLING TEMPLATE	20
4.3 Circuit breakers	6		
4.4 Remote control electric panel board	6	12 WARRANTY CONDITIONS	21
4.5 Wiring diagram	7	12.1 Conditions and limits	21
5 USE OF THE ANCHOR WINDLASS	8	12.2 Exceptions	21
5.1 Lowering the anchor	8	12.3 Liability	21
5.1.1 Lowering the anchor electrically	8	12.4 Procedure	21
5.1.2 Lowering the anchor by gravity	9	12.5 Clause of Termination	21
		12.6 Compliance	21

PRODUCT COMPLIANT WITH EC REGULATIONS

1 INTRODUCTION

1.1 Purpose of the manual

This manual will supply information on safety and correct use of the product. Follow these warnings carefully to avoid possible accidents or damages.

DANGER!

A warning such as this indicates the existence of a serious risk that has high probabilities to cause death or a serious accident if appropriate precautions are not taken.

ATTENTION!

A warning such as this indicates a reference to the application of safety practices, or draws the attention on unsafe behaviours that might cause personal injuries or damages to the boat.

1.2 Assistance

The Lofrans products are backed throughout the world by a network of authorised distributors and assistance. In case of need, please contact your local Lofrans s.r.l distributor. Details on website www.lofrans.com.

UK

1.3 Receipt and Storage

Upon receipt of the package, verify the integrity of packing. Should it be necessary to store the product for a prolonged period, keep it in a dry and protected place.

2 SAFETY INFORMATION

Safety standards and certifying bodies require peremptorily that, during the standing of the anchor, the load must be held by a chain stopper or a high resistance fixing point. The user is responsible for guaranteeing that during navigation the anchor is properly stowed and fixed. This precaution is more important when the navigation speed is higher and sea conditions are worse. Indeed, an anchor paid out by mistake during navigation can have very serious effects. Considering its position and not always frequent use, the anchor windlass is particularly exposed to oxidation and corrosion risk; therefore, it is necessary to arrange a constant inspection of its parts and a due maintenance. Make sure to have read and understood every part of this manual before proceeding with installation and use. Only persons who know how to operate should be authorised to use the anchor windlass. Should there be doubts on its installation or use, refer always to a skilled consultant

- Anchor windlasses used in an inappropriate way can cause damages to persons and/or things.
- Pay the utmost attention during the use of powerful equipment.
- Even the most careful use can be a source of damages, even serious.
- Lofrans products are supplied exclusively for recreational nautical use. Lofrans declines all responsibility for improper uses.
- Pay the utmost attention so that arms, legs, fingers, hair, and clothes do not get entangled in the chain or gipsy.
- Before operating the capstans, make sure that there are no persons in water in the vicinity.
- When the capstan is not used, the anchor must always be fixed to a solid point in order to avoid damages.
- The anchor windlass must never be used as mooring point. The load must always be held by a specific leaf or solid point.
- The capstan must not be used for functions other than paying out or weighing the anchor.
- The chain must never be used on the warping drum.
- The system must always be protected by a suitable circuit breaker.
- Disconnect always the circuit through the circuit breaker when the anchor windlass is not in use.

3 INSTALLATION

3.1 Contents of the package

In addition to the present manual, the package contains:

- ✓ Anchor windlass complete with motor reducer
- ✓ Control box (for DC variants)
- ✓ Handle
- ✓ Screws

3.2 Equipment necessary for installation


- ✓ Drill
- ✓ 10 mm bit for wood and steel
- ✓ 65 mm diameter hollow drill bit
- ✓ 10 mm., 13 mm., and 17 mm. hexagon keys

3.3 Recommended accessories

Use exclusively original Lofrans accessories and spare parts, designed and manufactured to ensure performances, duration and for keeping valid the warranty. For information on available spare parts, contact your local reseller or visit website www.lofrans.com.

3.4 General requirements for installation

In order to operate the anchor windlass correctly, it must be installed to meet the following conditions:



1. Bow roller alignment: the precise alignment of the anchor windlass to the bow roller is essential for the correct operation of the anchor windlass.

2. The parallelism between deck floors must be guaranteed; should it not occur, duly compensate the difference.

3. Chain locker depth: the chain fall into the chain locker must be such that when the chain is completely stored, there must be a minimum of 300 mm. between the underside of the deck and the top of the heaped chain.

4. Bow roller height: it must be such to guarantee a chain inclination lower than 5 degrees.

 Non-observance of these requirements will cause the malfunctioning of the anchor windlass and voidance of warranty.


3.5 Prevention from electrolysis

For aluminium boats, it is essential that the anchor windlass be insulated from the deck through a non-conductive gasket (not supplied). In addition, it is important that also the anchor and the chain be insulated from the hull, including chain stopper and fixing systems.



 Without these precautions, the electrolysis phenomenon will lead to a rapid corrosion of the anchor windlass.

3.6 Deck thickness

The area of the deck where the capstan is mounted must be solid and resistant so to be able to support the stresses due to the recovery of the anchor. The standard series studs allow an admissible range of deck thickness from 60 to 90 mm. Upon request, different deck thicknesses may be provided.



3.7 Deck installation



UK

 Chain pipe installation is suggested in order to guide the chain properly aligned to the chain locker and keep windlass efficiency high*

1. Place carefully the drilling template on the deck, by ensuring the **correct alignment** with the bow.
2. Mark and drill as indicated in the figure. Let the edges of the holes sharp, while the edge side of the holes of the chain towards the bow must be smoothed for an angle of 45° degree.
3. Place carefully the upper part of the anchor windlass on the deck.

Note:



It is recommended to seal the base of the anchor windlass to the deck by means of silicone glue. Do not use a permanent glue to fix the base of the anchor windlass to the deck since this will make difficult the removal in case of maintenance or intervention.

*Chain Pipe Selection

Code	636311	636312	636313	636314
for windlass	SX2 & SX3	SX3.5	SX4	SX5

3.8 Under deck installation


1. Grease the main shaft
2. Join the reducer to the upper part by aligning the motor far from the chain hole.
3. Screw washers and related nuts to the studs by fastening them appropriately.
4. Connect the cables coming from the battery to the electric motor by following the indications of the wiring diagram
5. For models up to 1500W the package of the windlass will include an IP cover, which protects the motor from direct water contact and provides the IP67 rating. The IP cover must be installed, in order for the windlass to have a valid warranty.



ATTENTION! Always disconnect electrical power to the anchor windlass before carrying out any operation.

3.9 Chain insertion

In order to guarantee performances and reliability, it is recommended to use a calibrated chain of the measure corresponding to the gipsy supplied.



1. Insert the chain into the hole and fix to a safe point.
2. Wrap the chain in the gipsy.
3. Recover all the chain by using the motor, taking care that the chain enters into the gipsy well aligned.

ATTENTION! Insert always an articulated joint between the chain and the anchor so that the chain itself does not turn into a spiral.

4 ELECTRICAL SYSTEM

Model	Motor Power (W)	Voltage (V)	Contactor (A)	Cable sizing according length of cable (positive + negative)			
				15-25 m	50-75 ft	> 25 m	> 75 ft
SX3.5	1700	24	70	25 mm ²	3 AWG	35 mm ²	2 AWG
	2000	24	70	25 mm ²	3 AWG	35 mm ²	2 AWG
	2300	24	125	50 mm ²	2 AWG	75 mm ²	000 AWG
	2700	24	125	50 mm ²	2 AWG	75 mm ²	000 AWG

4.1 Electrical cable section

In order to obtain the maximum performances from the anchor windlass and safeguard the electrical system, it is essential that the anchor windlass be wired with cables of sufficient section as suggested in the table.

4.2 Contactor (Control Box)

Place it in a dry place near the capstan.



4.3 Circuit breakers

The circuit breakers recommended by Lofrans have an intervention curve and not a simple plate value. The switches selected for each model guarantee the correct operation of the system.

4.4 Remote control electric panel board

The remote control electric panel board must be mounted in a comfortable position (such as the deck, the rudder or the cockpit), so that the operator can see the capstan during the manoeuvre. Mount and seal the electric panel board so that the terminals remain in a dry place.

4.5 Wiring Diagram



5 USE OF THE ANCHOR WINDLASS


5.1 Lowering the anchor

Lowering of the anchor can be carried out through the electric control or by gravity.

5.1.1 Lowering the anchor electrically

1. Make sure that the clutch is tightened and the brake is disengaged. Disengage all chain fixing devices.
2. Activate the safety switch
3. Press the DOWN button from the control at your disposal. In this way, the lowering of the chain will be perfectly controllable and the unwinding of the chain regular.
4. Once the chain is lowered, deactivate the safety switch.
5. Engage the chain fixing devices.


! During the use of the anchor windlass, do not change directly from one direction to the other but wait until the anchor windlass stops before manipulating the control into the opposite direction



5.1.2 Lowering the anchor by gravity

1. Make sure that the clutch is tightened and then disengage the chain stopper or safety stops. Disengage the brake.
2. Disengage the clutch gradually through the manoeuvre handle. Note: to adjust the descent speed of the chain act, through the handle, on the clutch. By turning it clockwise, the braking speed of the chain will increase (until complete stop), while by turning it anticlockwise, braking will be reduced.
3. Fix the chain to a strong point.




! Make sure the anchor windlass is not powered before carrying out manual interventions.



! By disengaging completely the clutch, the anchor will be lowered at high speed. Consequently, the fast passage of the chain into the hood and bow roller could damage them. It is recommended always to check the speed.

5.2 Weighing the anchor

1. Make sure that the hydraulic magnetic circuit breaker is activated.
2. Make sure that the clutch is well tightened and the **brake is disengaged**. Take out the manoeuvre handle from the drum or gipsy.
3. Disengage the chain stopper and safety stops.
4. Press the UP button from the control at your disposal until the anchor reaches its position inside the bow roller.
5. Deactivate the hydraulic magnetic circuit breaker.
6. Fix the chain with the chain stopper. In this way a potential damage of the anchor windlass will be avoided as well as unexpected chain releases.



 Do not carry out the anchor recovery operation by relying only on the onboard batteries. Start the motor of the boat (or the generator) to obtain the necessary electromotive force.




UK

To safeguard the anchor windlass, the hydraulic magnetic circuit breaker is sized so that it comes into action when the anchor windlass is subjected to higher loads than those for which it has been designed. Should it get released owing to an overload reactivate it again and wait some minutes before operating it; waiting for the operation after an overload is necessary to allow the circuits to cool and recover their functionalities.

 The hydraulic magnetic circuit breaker does not protect against an excessive increase in the motor temperature due to a prolonged operation of the anchor windlass. Therefore, give the motor the necessary time to cool, to avoid possible damages to the motor thereof.

5.3 Use of the warping drum

The warping drum can be used regardless of the gipsy, to help the mooring manoeuvres.




1. Tighten the brake and make sure that the anchor is appropriately blocked.
2. Insert the manoeuvre handle into the drum and disengage the clutch by turning it clockwise. This operation will make the drum independent of the gipsy.
3. Turn **clockwise** around the drum with three laps of rope.
4. By keeping the end of the rope, press the UP button and carry out the mooring manoeuvre.
5. Once the manoeuvre is ended, remove the rope from the drum and fasten it to a bollard.
6. Deactivate the safety switch.

 Always remove the manoeuvre handle when not in use.

5.4 Notes for use

During mooring, the load on the chain can be very high due to current, wind and waves.



- ⚠ Mooring, do not use the anchor windlass as strong point but always use a chain stopper.
- ⚠ If during recovery, the anchor windlass should block, slip or turn into self-protection mode, check the cause before proceeding.

1. By paying out the chain, it is necessary to manoeuvre so that the chain is laid down on the seabed without heaving on itself.
2. To ease the recovery and not overloading the capstan, steer up in a way that the boat slowly moves on the vertical of the anchor.
3. When the anchor is in the vicinity of the bow roller, slow down the recovery to check at best the insertion of the anchor into the seat.

6 MAINTENANCE

	USE OF THE YACHT (MONTHS)			
	LESS THAN 2	FROM 2 UP TO 6	MORE THAN 6	CHARTER
EVERY 3 MONTHS	A - A		A - B	A - B
EVERY 6 MONTHS		A - B		
EVERY 12 MONTHS	A - B - C	C	C	C - D
EVERY 24 MONTHS		D	D	E
EVERY 36 MONTHS	D - E	E	E	



- ⚠ Follow strictly the maintenance programme. Not meeting the maintenance programme will cause forfeiture of the warranty.
- ⚠ Disconnect power to the anchor windlass before any maintenance.

6.1 Maintenance programme

- A. Clean all external surfaces and hidden points with fresh water and soft cloth or non abrasive sponge to remove all salt layers. Do not use chlorine, bleach or acid solutions to clean the windlass as this will damage the INOX parts and the seals. Apply metal polish compound and coat all INOX parts to remove oxidation and renew the bright finish of the material.
- B. Grease the rotating parts with yellow marine grease that is non conductive. Particularly, the main shaft threads and clutch cones. Check for evidences of corrosion and mechanical stresses. Apply anti seize grease to the clutch nut and main shaft thread (635479+630821)
- C. Check the terminals of the electric motor. Test the voltage drop at the terminals.
- D. Replace all gaskets.
- E. Remove the anchor windlass from the deck to clean the salt under the base and seal again.

6.2 Gipsy maintenance/replacement

1. By turning anticlockwise, remove the hand-wheel of the gipsy through the manoeuvre handle.
2. Slip off from the shaft the upper clutch cone, the gipsy, and the lower clutch cone.
3. Wash with running water. DO NOT USE WATER UNDER PRESSURE.
4. Check that there is no evidence of corrosion or mechanical stresses.
5. Reassemble by proceeding in the reverse order, remembering to lubricate threads and all moving parts with grease.



7 TROUBLESHOOTING

Problem	Possible causes	Solution
1. The anchor indlass does not work when a control is operated	1.1 Protection switch in OFF position 1.2 Lack of voltage in the system 1.3 Failure of the control box 1.4 Failure of the control 1.5 Failure of the electric motor	1.1 Check the protection switch and set it in the ON position 1.2 Check the charge status of the battery, check connections 1.3 Check and possibly replace the control box 1.4 Check and possibly replace the control 1.5 Measure the electric motor voltage; if it is OK, check the brushes and clean them. If it does not work, replace the electric motor
2. The chain jams frequently	2.1 The chain locker is not deep enough with respect to the quantity of chain chosen 2.2 The chain is not suitable for the gipsy 2.3 The chain is not calibrated	2.1 Position the anchor windlass in the deepest point of the chain locker or reduce the quantity of chain 2.2 Change the gipsy 2.3 Check the chain: if it does not meet the tolerances, it must be replaced
3. The anchor windlass turns slowly	3.1 Unsuitable cable sections 3.2 Deck floors not parallel 3.3 Bad electrical connections 3.4 Dirty brushes 3.5 Water infiltrations in the electric motor	3.1 Increase cable section 3.2 Make floors parallel by interposing thicknesses 3.3 Check connections 3.4 Clean brushes 3.5 Replace the electric motor

UK

Problem	Possible causes	Solution
4. The electric engine runs but the shaft does not rotate either Up or Down	<p>4.1 Heavy wear or breakage of teeth of the crown / worm screw.</p> <p>4.2 Breakage of the engine spindle.</p>	<p>4.1 (SERVICE) Uninstall the winch and replace the broken parts. Check out carefully that pieces or splinters of broken parts did not enter into the oil circuit and have ruined other mechanical parts. (*)</p> <p>4.2 (SERVICE) Replacing of the engine. Care must be taken that the broken part did not remain in the hole of the worm screw. (*)</p> <p>(*) Take advantage of this opportunity to replace any other worn parts, especially gaskets, screws, tabs, seeger, and oil.</p>
5. The electric engine runs, the shaft rotates Up, but does not rotate Down	<p>5.1 The chain locker is tangled; therefore, the emergency mechanism becomes operative.</p> <p>5.2 The chain is of poor quality with burrs and zinc deposits that do not allow the free flow of the links; therefore, the emergency mechanism becomes operative.</p> <p>5.3 The chain was placed in the locker in block and the links are stuck with each other; therefore, the emergency mechanism becomes operative.</p> <p>5.4 Wear of the emergency mechanism of the spring control.</p> <p>5.5 The chain stripper interferes with the gypsy: it is possible to weigh the operation, while to lower, the emergency mechanism becomes operative.</p>	<p>5.1 Check out that immediately after the anchor there is a joint that allows the chain to unfold properly when weighed.</p> <p>5.2 Remove the chain from the locker and inspect it link by link. Intervene with the appropriate tools to make it as loose as possible and free of obstructions.</p> <p>5.3 Lower manually all the chain in a sea bed deep enough to enable it to unfold properly. Retrieve it with the winch.</p> <p>5.4 A (SERVICE) Uninstall the winch from the boat and disassemble it into its parts by replacing the spring. Take advantage of this opportunity to replace any other worn parts, gaskets, screws, tabs, seeger, and oil.</p> <p>B (SERVICE) It is possible to block the EMERGENCY MECHANISM so that the gears are always engaged both in UP and in Down. This operation must be authorized by the shipowner. The solution rules out completely the possibility of carrying out the emergency operation.</p> <p>5.5 Restore the condition of the chain stripper by repositioning properly in the gypsy centreline. If it is deformed. It must be replaced.</p>
6. The electric engine runs but it cannot be bell warped.	6.1 The bell warp is being used wrongly; therefore, the emergency mechanism becomes operative	6.1 To carry out the warping operation the main shaft must run in the same rotation direction of the winch gypsy when it weighs the chain.
7. The winch cannot be weighed: the electric engine runs, the shaft runs, but the gypsy is still although the brake belt is loose.	<p>7.1 The gypsy is not closed on the clutch cones and slips under the load effect, or for some reason the closing wheel is at end stroke. Check out all pieces in sequence.</p> <p>7.2 The clutch cones or the gypsy cones are deformed and the clutch hubs are in contact and prevent closure.</p>	<p>7.1 Check out clutch tightening. If necessary, measure the parts and check out possible deformations. It is possible to add some thickness to stem the problem. Then replace the damaged parts.</p> <p>7.2 Replace the clutch and/or the gypsy</p>
8. The shaft does not run well, is not aligned, and so is the gypsy and/or the bell.	8.1 The shaft bent because the winch was subjected to an excessive load.	8.1 Check out that the procedures of use fall within the specifications of the winch. (SERVICE) Uninstall the winch and replace the shaft. Take this opportunity to replace worn parts, gaskets, seeger, tabs and oil.

Problem	Possible causes	Solution
9. Loss of oil between the engine and the gearbox body	9.1 The coupling of the engine is loose and causes the worm screw into an irregular rotation, leading to loss of oil from the gasket.	9.2 (SERVICE) Find the reasons why the screws or nuts have become loose. Uninstall the engine and check out the status of the spindle and the hole of the worm screw. If an oval form of the cylindrical part of the screw is observed (outer hole and diameter) uninstall the winch and repair the damaged parts on the bench. Check out if the oil has entered into the electrical engine. Take this opportunity to replace all gaskets, tabs, seeger, screws, oil, and any worn parts.
10 On installation, it is found that the shaft and the studs are short for a correct coupling with the gearbox.	10.1 The request referred to the deck thickness was wrong.	10.1 If the key shaft works in the gearbox along all its length, the fixing studs can be adapted. Otherwise, a longer shaft must be requested.
11 The winch runs slowly and at times jumps the circuit breaker.	11.1 Section of cables not suitable. 11.2 Poor electrical connections. 11.3 Dirty brushes. 11.4 Water leaks in the electrical engine. 11.5 There is no parallelism between upper deck and below deck. 11.6 The gearbox has lost oil. 11.7 The engine strains in one or both directions. 11.8 The winch works only in one direction.	11.1 Increase the cable section 11.2 Check out the connections 11.3 Clean the brushes 11.4 Replace the electrical engine 11.5 Work surfaces and/or add shims to restore parallelism. 11.6 (SERVICE) Uninstall the gearbox and check out its condition. Replace damaged parts after discovering the causes of the leak. Also, replace gaskets and screws. Check out also the engine condition, which may have been damaged during the malfunction. 11.7 (SERVICE) Check out appropriately all connections of the power cables. If they are alright, uninstall the engine (in some cases it is convenient to disassemble also the gearbox). Check out and possibly replace the brushes. 11.8 Check out on the control box that between B2-C and B3-C contacts there are 12/24V when the respective buttons are pressed. If this should happen and one of the relays does not work, replace the control box.


UK

8 TECHNICAL DATA


Motor Power	1700W		2000W	2300W	2700W
Vessel Length Heavy Duty (ft)	55-65		60-70		
Vessel Length Light Duty (ft)	60-70		65-75		
Power Supply	12V	24V	24V	24V	24V
Maximum linear Load/Pull (lb)	1700 / 3740	1750 / 3850	1900 / 4180	2000 / 4400	2400 / 5280
Maximum lift Load/Pull (lb)	850 / 1870	875 / 1925	950 / 2090	1000 / 2200	1200 / 2640
Max Lift Working Load (lb)	215 / 473	220 / 484	250 / 550	265 / 583	320 / 704
Amps Work Load (A)	135	68	90	110	125
Max Line Speed (ft/min.)	32 / 96	32 / 96	30 / 90	30 / 90	32 / 96
Line Speed (ft/min.)	15 / 45	15 / 45	16 / 48	18 / 54	18 / 54
Net weight with Drum (lb)	50 / 110	50 / 110	55 / 121	60 / 132	60 / 132
Net weight Low Profile (lb)	46 / 102	46 / 102	51 / 113	56 / 124	56 / 124

Gipsy	10mm		10 DIN 766		12 mm		13 DIN 764		14 mm	1/2"HT	1/2"BBB
Chain supported	10mm	3/8"	10mm	3/8"	12mm	13	7/16"	13	14 mm	1/2"	1/2"

9 SPARE PARTS



UK



X3.5 170W-2000W


Item	Description	Kit	Q.ty
209	Key 6x6x30	Kit C	1
227	Nut M8	Kit B	4
250	Hd cap screw M5x8	Kit B	1
307	Spring washer for M8 screw	Kit B	2
308	Washer for M8 screw	Kit B	2
309	Bearing 6203		1
311	Bearing 51105		1
312	Circclip - 43 Din 472	Kit D	1
351	Hd cap screw M6x20	Kit B	7
368	Pivot		1
378	Circclip - 62 Din 472	Kit D	1
382	Key - 8x7x160		1
450	Key - 8x7x80		1
453	Bearing 6206		1
507	Brake cover		1
534	Gearcase - upper		1
535	O Ring 4500	Kit A	1
536	Seal 45-80-7	Kit A	2
537	Bearing 16009		2
546	Seal 25-45-10	Kit A	1
639	Washer	Kit B	4
796	Hd cap screw M10x20	Kit B	2
830	Seal 30-45-8	Kit A	1
937	Brake pivot		1
938	Knob		1
1003	Spiral retaining ring		2
1030	Magnet		1
1031	Sensor		1
1033	Stud M8x105		4
1233	Base		1
1238	Key - 8x7x18		1
1281	Seal 30-52-7	Kit A	1
1282	Clutch nut		1
1283	Circclip - 45 Din 472	Kit D	1
1284	Drum		1
1285	Band brake		1
1287	Barbotin Guide		1
1288	Stripper		1
1289	Clutch cone - inner		1
1290	Main shaft		1
1291	Chain guide		1
1317	Worm		1
1318	Spacer		1
1319	Gearcase - lower		1
1321	Electric motor 2000W 24V B14		1
2002	Wormwheel		1
1320a	Electric motor 1700W 12V B14		1
1320b	Electric motor 1700W 24V B14		1
1322a	Gipsy chain 10 Iso - 3/8" G40		1
1322b	Gipsy chain 3/8" Din766 - BBB - 10 Din766		1
1322c	Gipsy chain 12 Iso - 13 Din766 - 1/2" Din766		1


X3.5 2300W-2700W

Item	Description	Kit	Q.ty
226	Washer for M8 screw	Kit B	14
250	Hd cap screw M5x8	Kit B	1
255	Key - 6x6x25	Kit C	1
259	Hd cap screw - M8x16	Kit B	4
260	Spring washer for M8 screw	Kit B	14
361	Seal - 40x50x5	Kit A	1
368	Pivot		1
378	Circclip - 62 Din 472	Kit D	1
382	Key - 8x7x160		1
389	Stud M10x140		4
390	Washer for M10 screw	Kit B	2
391	Nut M10	Kit B	4
392	Hex hd screw - M8x25	Kit B	15
393	Gearcase - upper		1
394	O ring seal - 4625	Kit A	1
395	Seal - 50x70x10	Kit A	2
396	Bearing - 16010		2
412	O ring seal - 153	Kit A	2
414	Hex hd screw - M8x30	Kit B	4
419	Electric motor 2300W 24V		1
433	Electric motor 2700W 24V		1
450	Key - 8x7x80		1
453	Bearing 6206		1
507	Brake cover		1
675	Spacer		1
786	Hd cap screw M10x20	Kit B	2
812	Worm		1
830	Seal 30-45-8	Kit A	1
937	Brake pivot		1
938	Knob		1
1003	Spiral retaining ring		2
1030	Magnet		1
1031	Sensor		1
1084	Gearcase - lower		1
1086	Flange		1
1087	Motor flange DC motor		1
1093	Bearing 6002		1
1233	Base		1
1238	Key - 8x7x18		1
1241	Wormwheel		1
1281	Seal 30-52-7	Kit A	1
1282	Clutch nut		1
1283	Circclip - 45 Din 472	Kit D	1
1284	Drum		1
1285	Band brake		1
1287	Barbotin Guide		1
1288	Stripper		1
1289	Clutch cone - inner		1
1290	Main shaft		1
1291	Chain guide		1
1318	Spacer		1
1322a	Gipsy chain 10 Iso - 3/8" G40		1
1322b	Gipsy chain 3/8" Din766 - BBB - 10 Din766		1
1322c	Gipsy chain 12 Iso - 13 Din766 - 1/2" Din766		1
632b	Gipsy chain 14		1
	Bearing 51108		1


UK

10 OVERALL DIMENSIONS





11 DRILLING TEMPLATE



12 WARRANTY CONDITIONS

Lofrans guarantees that in a normal use and by meeting the maintenance programmes, the anchor windlass is covered by a warranty for a period of **3 years** from the date of purchase by the ultimate user, subject to the conditions, limitations, and exceptions listed hereunder. Any product that proves to be defective in a normal use during this period will be repaired or replaced at the choice of Lofrans.

12.1 Conditions and limits

- Lofrans liability will be limited to the repair or replacement of all parts of the product that show material or processing defects.
- Lofrans is not liable for the wrong choice of the anchor windlass by the purchaser.
- Lofrans will not be liable in any whatsoever manner for failures, or any consequent damage deriving from:
 - use of the anchor windlass in an application for which it was not designed or envisaged;
 - corrosion, degradation by UV rays and wear;
 - non-observance of the maintenance plan;
 - wrong or unsuitable installation of the product;
 - any modification or alteration of the product;
 - conditions of use beyond the specifications and the performances of the product;
- Except for different directives given directly by Lofrans, any product subject to a warranty request must be returned to Lofrans, which will analyse the problem.
- The warranty does not cover the accessory costs met for interventions, removal, transport, and installation of the product;
- Maintenance carried out by persons not authorised by Lofrans will invalidate this warranty;
- The Lofrans products are intended to be used only in a marine environment. Lofrans is not liable should these products be used differently.

12.2 Exceptions

The cover under warranty of the following components is limited to a period of one year from the date of purchase by the ultimate user:

- Electric motors and related electric equipment
- Electronic controls
- Hydraulic pumps, valves, and actuators
- Gaskets and seals
- Products used on charter boats.

12.3 Liability

The liability of Lofrans on this warranty is intended dependant on meeting the regulations and laws in force.

Lofrans is not liable for any other kind, such as:

- Any loss of turnover, advances, or direct or indirect profits, or any other financial loss;
- Damages, costs or expenses payable to third parties;
- Damages to yachts or equipment;
- Death or personal injuries (unless caused by negligence of Lofrans). Certain States and Countries do not allow the exclusion or limitation of incidental or consequential damages, therefore the aforementioned limitations or exclusions might not be applicable.

12.4 Procedure

Every request for intervention under warranty will be made promptly and in writing by the ultimate user to the local Lofrans assistance centre.

12.5 Clause of termination

If any whatsoever clause of this warranty will be invalidated by a Judge or other competent authority, the validity of the remaining clauses of this warranty and the rest of the clause in question will not be affected.

12.6 Compliance

This warranty is governed by the laws and in compliance with the Italian Laws or the State or Country in which the ultimate user is domiciled at the time of purchase of the product.



Via Philips, 5 - 20052 Monza (MB) (Italy)
www.lofrans.com - e-mail: contact@lofrans.com