

FOOTSWITCHES

DOWN

UP

Black

Green


ROCKET SWITCH TYPE C



- 8 - Black connector
- 2 - Battery +
- 3 - Green Connector

Black

Red



Black connector

Green connector



Battery

Fuse
5 A